

DIY Wood and Upholstered Headboard

Free Plans by The Craft Patch

www.thecraftpatchblog.com

Boards	Cutting Instructions	Piece Name
One - 1"x2"x6'	Round over 1 edge top and bottom using a 3/8" roundover bit. Cut one piece to 56" in length.	Routed Trim Piece
Two - 1"x2"x6'	Round over 1 edge top and bottom using a 3/8" roundover bit. Cut to 3/4" in width. 45 degree miter cut two pieces at 49" in length and two pieces at 19" in length. See tutorial for more details on the miter cuts.	Upholstered Panel Frame Trim
One - 1"x2"x6'	Cut to 56" in length.	Bottom Filler Piece
One - 1"x4"x6'	Cut to 57-1/2" in length.	Center Panel Top Rail
One - 1"x4"x6'	Cut two 19" pieces in length.	Center Panel Stiles
Two - 4"x4"x6'	Cut down each side by 1/8" inch so that the final measurement is 3-1/4" square. Cut to length at 61 inches.	Post Centers
Four - 1"x6"x6'	Cut one edge at 45 degrees with the inside measurement being 3-1/4" and the outside measurement being 4". Cut to length at 61 inches.	Post Sides
Two - 1"x6"x6'	Cut one edge at 45 degrees, being sure not to waste any wood. Cut the other edge at 45 degrees, with an inside measurement of 3-1/4" and an outside measurement of 4-3/4". Cut to length at 61 inches.	Post Faces
One - 1"x6"x6'	Cut to 4-3/4" width and 67" in length.	Top Trim Piece
One - 1"x6"x6'	Cut to 57-1/2" in length.	Center Panel Bottom Rail
One - 1"x8"x6'	Cut to 6-1/2" in width and 57-1/2" in length.	Top of Center Panel
One - 5' Crown Molding	Cut to 56" in length.	Crown Molding
1/4 Inch Plywood	Cut an 18-7/8" x 48-7/8" rectangle.	Upholstered Panel Backing

For full written instructions, please visit
<https://www.thecraftpatchblog.com/diy-headboard/>

or view the video tutorial on YouTube
<https://youtu.be/3uUi5-DMS0Q>